

Analysis Results of Fish
<Sampled from the Port Area of the Fukushima Daiichi Nuclear Power Station>

(1/2)

Place of Sampling	Name of Sample (Region)	Date of Sampling	Analysis Item		
			Cs-134 (Bq/kg(Raw))	Cs-137 (Bq/kg(Raw))	Cs (Sum) (Bq/kg(Raw))
Port area (Near southern seawall)	Stingray (muscle) No.1	2024/4/26	< 2.4E+00	< 2.4E+00	ND
Port area (Near southern seawall)	Brown hakeling (muscle) No.1	2024/4/26	< 6.8E+00	2.0E+01	2.0E+01
Port area (Near southern seawall)	Drumfish (muscle) No.1	2024/4/17	< 3.1E+00	3.6E+00	3.6E+00
Port area (Near southern seawall)	Common Japanese conger (muscle) No.1	2024/4/26	< 5.5E+00	1.5E+01	1.5E+01
Port area (Near northern seawall)	Marbled sole (muscle) No.1	2024/4/24	< 2.7E+00	1.2E+01	1.2E+01
Port area (Near northern seawall)	Marbled sole (muscle) No.2	2024/4/26	< 2.7E+00	1.1E+01	1.1E+01
Port area (Near northern seawall)	Marbled sole (muscle) No.3	2024/4/26	< 2.5E+00	1.2E+01	1.2E+01
Port area (North of eastern wave breaker)	Striped mullet (muscle) No.1	2024/4/26	< 2.4E+00	< 2.2E+00	ND
Port area (North of eastern wave breaker)	Striped mullet (muscle) No.2	2024/4/26	< 3.2E+00	< 2.3E+00	ND
Port area (North of eastern wave breaker)	Striped mullet (muscle) No.3	2024/4/26	< 2.4E+00	< 2.3E+00	ND

- Inequality sign (<: less than) indicates that measurement result is less than the detection limit (ND).
- Values are expressed in exponential notation. For example, "3.1E+01" means "3.1×10¹" and equals 31. Similarly, "3.1E+00" means "3.1×10⁰" and equals 3.1, and "3.1E-01" means "3.1×10⁻¹" and equals 0.31.

Analysis Results of Fish

<Sampled from the Port Area of the Fukushima Daiichi Nuclear Power Station>

(2/2)

Place of Sampling	Name of Sample (Region)	Date of Sampling	Analysis Item		
			Cs-134 (Bq/kg(Raw))	Cs-137 (Bq/kg(Raw))	Cs (Sum) (Bq/kg(Raw))
Port area (North of eastern wave breaker)	Striped mullet (muscle) No.4	2024/4/26	< 2.8E+00	< 2.3E+00	ND
Port area (South of eastern wave breaker)	Drumfish (muscle) No.1	2024/4/26	< 1.9E+00	< 2.1E+00	ND
—	—	—	—	—	—
—	—	—	—	—	—
—	—	—	—	—	—
—	—	—	—	—	—
—	—	—	—	—	—
—	—	—	—	—	—
—	—	—	—	—	—

- Inequality sign (<: less than) indicates that measurement result is less than the detection limit (ND).
- Values are expressed in exponential notation. For example, "3.1E+01" means "3.1×10¹" and equals 31. Similarly, "3.1E+00" means "3.1×10⁰" and equals 3.1, and "3.1E-01" means "3.1×10⁻¹" and equals 0.31.